



TW 402

Teppichadapter
Adapteur tapis
Carpet tool

B 7 / ST 7

Schmutz- und Frischwassertank
Seau d'eau sale et Seau d'eau propre
Waste water tank and Clean water tank

B 1 / ST 1

Einbau Saugmotor
Montage de la
moteur d'aspiration
Vacuum motor
assembling

B 5 / ST 5

Einbau Pumpe
und Netzzuleitung
Montage de la pompe
et Cable d'alimentation
Pump assembling
and Electrical connection

B 3 / ST 3

Pumpe
Pompe
Pump

B 4 / ST 4

Chassis und Laufrad
Chassis et Roue
Chassis and Wheel


B 2 / ST 2

Teppichadapter
Adapteur tapis
Carpet tool

B 7 / ST 7

Stromlaufplan
Diagramme électrique
Wiring diagram

B 9 / ST 9



Polsteradapter
Adapteur pour ameublements
Upholstery tool

B 8 / ST 8

TW 402

Waste water tank and Clean water tank

Stand: 22.06.2021 12:17

Position	Ersatzteilenummer	Description
1	041.409	Cover
2	P480C	Countersunk screw M 4
3	041.412A	Seal for cover
4	400.766	Filter
5	041.499	Bent tube
6	041.460	Waste water tank
7	4012234	Hose connector
8	P515N	PT screw KA 50x35
9	P515M	PT screw KA 50x30
10	649012512	Seal
11	041.452	Deviation
12	430.734	Angled piece
13	P516P	PT screw KA 40x12
14	P476AB	Pan head screw M 6x20
15	P497K	Washer M 6
16	041.456	Locking device
17	P498X	Spring washer
18	041.455	Distance piece
19	P488B	Cylindrical screw M 5x12
20	430.618	Distance piece
21	430.616	Hinge
22	041.410	Seal
23	041.407	Reinforcing piece
24	041.430	Clean water tank
25	P516H	PT screw KA 50x16
26	041.440	Handle
27	041.423	Filling indicator
28	041.421	Filling funnel

TW 402

Chassis and Wheel

Stand: 22.06.2021 12:17

Position	Ersatzteilenummer	Description
1	041.470	Carrying handle
2	P496Q	Washer M 8
3	380.135	Wheel
4	041.404	Distance piece
5	041.403	Hexagon screw M 8x70
6	300.242	Wheel cover
7	041.469	Transporting handle
8	P475T	Pan head screw M 6x12
10	P496S	Washer M 10
11	P204B	Castor
12	P498E	Spring ring M 10
13	P487H	Cylindrical socket screw M 10x20
14	041.580	Large air canal cpl.
15	P481P	Self tapping screw M 4x8
16	041.570	Small air canal cpl.
17	P496L	Washer M 6
18	380.137	Distance piece

TW 402

Pump assembling and Electrical connection

Stand: 22.06.2021 12:17

Position	Ersatzteilenummer	Description
1	P541I	Angled connector 1/4"
2	P535B	Hexagon nut 3/8"
3	P097	Sealing washer 30/17x2
4	041.054	Hose 6/8x90 mm
5	P528	Clean water filter
6	P098	Fixing washer 35,3x17x1,5
7	P535A	Reducer 3/8"-1/4"
8	P550I	Hose clamp 13,3
9	041.952	Hose 6/12x370 mm
10	041.910	Hose connecting nipple
11	041.951	PU hose 350 mm
12	P550A	Hose clamp 14,5
13	041.950	PVC hose 170 mm
14	P524F	Hose nipple 1/4"
15	P500A	Coupling
16	041.501	Bottom plate
17	042.414	PVC hose 120 mm (TW 402)
18	P542D	Y-piece 6 mm TW 402
19	042.415	PVC hose 95 mm TW 402
20	042.413	PVC hose 135 mm (TW 402)
21	P207A	Grommet
22	041.901	NDS-WX pump
22a	030.367	Switch TW 401
22b	041.970A	Switch TW 402
23	041.951	PU hose 350 mm TW 402
24	P551R	Hose clamp 9,0
25	P475T	Pan head screw M 6x12
26	041.920	Left pump holder TW 401
27	042.920	Right pump holder TW 402
28	P275	Mains cable SEV (CH), 3x1,5x7,5m
29	041.402	Cable holder
30	041.301	Switch
31	P279	Cable clamp
32	P280	Cable protection
33	P279H	Counter nut PG 9
34	124.313	Switch
35	P377C	Distribution box housing
36	041.350	Distribution box cover
37	P485J	Blind rivet 3 mm
38	P516S	PT screw KA 30x14
39	P390	Marking plate

40	P383A	Connection block (3)
41	124.323	Gasket

TW 402

Pump

Stand: 22.06.2021 12:17

Position	Ersatzteilenummer	Description
1	041.901	NDS-WX pump
2	P481M	Screw M4 x 10
3	P810M	Angled connector
4	P809M	Straight connector
5	P523G	Sleeved nut

TW 402

Vacuum motor assembling

Stand: 22.06.2021 12:17

Position	Ersatzteilenummer	Description
1	041.603	Left angle
2	041.602	Right angle
3	P498U	Spring ring M 6
4	P486Q	Cylindrical screw M 6x12
5	420.210	Vacuum motor 230 V/50 Hz
6	420.210KH	Pair of carbon brushes
7	041.601	Adaptor for vac motor
8	041.040	Suction hose 270 mm
9	P206D	Hose clamp 32-50
10	041.050	Exhaust hose 370 mm
11	041.501	Bottom plate
13	P013	Seal for motor
14	041.401	Lower guiding plate
15	041.605	Cable for vac motor
16	P485J	Blind rivet Ø 3x10
17	041.310	Controls pannel
18	P481A	Countersuck screw M 4x20
19	P498A	Spring ring M 4
20	P491Q	Hexagon nut M 4
21	041.320	Guiding plate

TW 402

Carpet tool for TW 402

Stand: 22.06.2021 12:17

Position	Ersatzteilenummer	Description
1	602.000	Carpet adapter 2 nozzles 26cm with plastic tube
2	P584	Chrome steel hand pipe cone 38mm
3	645.002A	Stainless steel tube INOX
4	602.550	Suction nozzle 26cm 2-hole machined + pre-assembled
6	P617	Carpet slide
7	602.611F	Mounting bracket for nozzle
8	602.110	Double pipe bend
9	P491E	Nut DIN 934 M6 A2
11	P499D	Washer DIN 6798 M6 6,4/11/0,7 A2
12	P472D	Screw M6 x 20
13	P523D	Cup nut SW19 x 12
14	P602M	Spraying jet grey
15	P607E	Nozzle filter
18	P670	Hose clamp
19	P683	Guide bride cpl.
22	P681	Spraying valve complete
23	P681A	Valve body
24	P501B	Tapped nipple 1/4" big
25	P681C	Valve lever
26	P681K	Cyl. pin 1,5/14,5
27	P681F	O-ring ID5,23/2,62 NBR
28	P681D	Valve pin cpl.
29	P681E	Valve spring
30	P497G	Washer DIN 125 A M5 5,3/10/1 A2
31	P681G	O-ring ID5/2 NBR
32	P681B	Cap nut
33	401.100	Spray and suction hose 3m cpl. including Items 33-42
34	P575	Hose socket
35	P562A	Vacuum hose NW32 x 3m
36	012.570	Hose end connector
37	041.701	Spraying hose including items 38-41
38	900.165	Quick connector LW6
39	P550I	Hose clamp 13,3-706R
40	P566H	Spraying hose, Ø11,5/6,3 Meterware, 3200mm
41	P501D	Nipple Ø12 x 46mm
42	P609	Cable tie black 4,8 x 178mm
?	P573A	PUR spray hose 6/8, 1055mm
?	P499H	Washer 6,4x12,5 mm
?	P535P	Reducer 3/8"
?	P499H	Washer 6,4x12,5 mm

TW 402

Upholstery tool

Stand: 22.06.2021 12:17

Position	Ersatzteilenummer	Description
1	617.000	Upholstery tool
2	617.623	Nozzle housing 8 cm
3	P683	Guide bride cpl.
7	617.624	Pipe Ø 33 mm
8	P627	Jet nozzle 11004
9	617.625	Pipe bend
10	P680	Spraying valve with fitting including Items 11-20
11	P680A	Valve body
12	P501B	Tapped nipple 1/4"
13	P681C	Lever
14	P681K	Cyl. Pin Ø 1,5x14,5 mm
15	P681F	O-ring Ø 5,23 mm
16	P681D	Valve pin
17	P681E	Valve spring
18	P497G	Washer M 5
19	P681G	O-ring Ø 5 mm
20	P681B	Cap nut